

# KENDALL + KYLIE

SMARTWATCH



(US)

**USER MANUAL VERSION 1.0**

"This iTouch Wearables smartwatch is NOT a medical device. This device and related software and applications are NOT intended for use in the diagnosis of disease or other conditions, or in the cure, mitigation, treatment or prevention of disease. Users should NOT interpret or take clinical action based on the device output without consultation of a qualified healthcare professional. "

<b>Getting Started</b>	<b>3</b>
What's in the box?	3
Charging Your Smartwatch	3
<b>Setting up K+K Smartwatch</b>	<b>4</b>
Download iTOUCH Wearables App	4
Connecting, Syncing & Pairing	4
Powering On/Off	4
<b>Basics</b>	<b>5</b>
Navigating K+K Smartwatch	5
Motion Gesture & Brightness	5
Changing Watch Faces	5
Navigation Tips	6
<b>Apps and Features</b>	<b>6</b>
Timekeeping	6
Notifications & Messaging	7
Activity Tracking & Sleep	7
Sedentary Reminder	8
Sleep Monitor	8
Heart Rate Monitor	8
Fitness & Exercising	9
Connected GPS	10
Camera & Music Remote	10
Additional Features	11
<b>Updating, Restarting, &amp; Erasing</b>	<b>12</b>
<b>Wear &amp; Care</b>	<b>12</b>
<b>Regulations and Safety Notices</b>	<b>13</b>

## Kendall + Kylie Smartwatch User Guide:

Everything you need to know about the Kendall + Kylie Smartwatch.

### What's in the box?

Your K+K Smartwatch box includes:

- K+K Smartwatch  
(Color and material vary)
- Clamp Charging Cable

*The interchangeable straps on the K+K Smartwatch come in a variety of colors and materials. Additional straps for the K+K Smartwatch are sold separately. Refer to proper URL or QR Code for additional bands (that are the proper size).*



### Charge Your Smartwatch

A fully charged K+K Smartwatch has an extended battery life of up to 15 days (standby time). **Battery life and charge cycles vary based on usage.**

1. Plug the charging cable into the USB port on your computer or a UL-certified USB wall charger. We recommend using the USB port on your computer.
2. Insert the Smartwatch into the appropriate charging cable section. A charging screen appears on the screen to indicate that your Smartwatch is charging.

**Note:** Your K+K Smartwatch takes about 1-2 hours to fully charge.



# SET UP YOUR SMARTWATCH

The free iTouch Wearables App is compatible with most iPhones and Android Phones.  
A smartphone is required for call, text, and smartphone app notifications.

## To get started:

1. Find the iTOUCH Wearables app in one of the locations below, depending on your smart device
  - Apple App Store for iPhones
  - Google Play Store for Android Phones



**Note:** Do not use your mobile device's bluetooth pairing to pair to the watch. To properly connect your iTouch Wearables smartwatch, follow the pairing instructions within the mobile application. If you have already connected your phone to the smartwatch disconnect and "forget" the bluetooth connection prior to setting up your watch through the application.

**\*YOUR DEVICE WILL ONLY WORK WITH THE ITOUCH WEARABLES APP ACCESSED BY THE QR CODE ABOVE.**



[For more information, manuals or application information, please visit the Help Center at www.iTouchWearables.com](http://www.iTouchWearables.com)

2. Download and install the iTOUCH Wearables App: The application will ask for permissions once installed and your account has been set up (New Users). We highly encourage the user to allow all notifications & pairing access to their smartphones for complete functionality.

Android Users: You will be asked to allow the iTouch Wearables App to access information in your device's native settings once your account has been set up. Not enabling these settings may prevent the application from working correctly.

3. Once the app is installed, open it to create an account, following the on-screen prompts to help you get set up. Once your account is set up, the application will help you connect to your device (We highly encourage the user to allow all notifications & pairing access to their smartphones.)
4. To connect & sync your fitness tracker to your device, please follow the on screen instructions while setting up your account.

---

## Power On & Off



Tap and hold the screen of your smartwatch for 5 seconds until you see the K+K Smartwatch logo appear on the watch screen, indicating the watch has powered on.



On the main clock face, swipe down from the top of the screen to reveal the notification panel. Tap the 'Settings' icon here and you will be taken to the settings screen. Scroll down to 'Power off'. After tapping on this selection, the device will ask if you're sure you would like to turn off the device. Once you tap on the blue check mark, the device will power off immediately.



Learn how to best navigate your K+K Smartwatch.

## Motion Gesture

Allows you to rotate your wrist to turn on your watch screen. Tap the 'Menu' located on the top left of the home screen. Then tap on 'Settings'. From here tap on, 'Motion Gesture', to access this function and set it up. You can control the time in which this feature is active throughout the day. If you want this feature to always be on, set the time constraints to be 12:00AM to 12:00AM. **Using this feature will consume more battery.**




## Brightness

Control the Brightness on your Smartwatch. From the Settings menu on your K+K Smartwatch, tap the brightness icon. Then tap on the minus icon to reduce the brightness or the plus icon to increase the brightness. Once you have set the brightness the way you like, swipe right on the screen to exit and save your changes.

You can also access the brightness section on your watch by utilizing the quick toggles/notification panel found on your device by tapping on the sun icon found there.

## Changing Watch Faces

Personalize your watch with our built-in watch faces to showcase your favorite K+K Smartwatch time-keeping features. The K+K Square Smartwatch comes with four interchangeable watch faces: Modern, Digital, Analog, and Custom.



### Change your watch face from the K+K Smartwatch:

The K+K Smartwatch comes with four interchangeable watch faces built into it. From the main clock face screen on your Smartwatch, hold the center of the screen for 3 seconds to switch the clock face. Swipe from left to right to see the selections. Tap on the clock face you want. Your smartwatch will vibrate once the clock face has changed.

### Change your watch face from the ITOUCH Wearables App:

**Setting a Custom Watch Face:** Create your own watch face! You can add your own image, format text, and put your favorite features on display.

In the iTouch Wearables App, from the Watch Faces page, tap on the **Custom** watch face panel to begin editing. Hit Save/Done to apply.

## BASIC NAVIGATION TIPS

Your K+K Smartwatch is a full touch device, you can swipe the screen in many directions to interact.

Here are a few basics to help you get started:

**Exiting a section or app on watch:** To exit an area you're in on the watch, you can swipe right on the screen. This is universally how you go back on this watch.

**View Messages:** On the main clock face, swipe up from the bottom of the screen to reveal your recent messages. (This is the only way to view older messages you received but may have not seen right way).

**Access the Notification Panel:** Like many phones, your watch has a notification panel. Your notification panel contains shortcuts that quickly take you wherever on the watch you would like to go. To view this, on your main clock face, swipe down from the top of the screen. You can turn off your watch, view weather, control vibration, and more! To exit this section, simply swipe up from your smartwatch.

**Haptic Feedback Control:** Your watch vibrates to alert you of any notifications or reminders you need. But sometimes if you don't want the vibration, it can become a bother. That's why you can control if you want vibration on or off for your watch. To turn off vibration on your watch quickly, on your main clock face, swipe down to reveal the notification panel. Near the 'Weather' icon, you will see a small device icon, this is the vibration control section. Tap it to turn it off/on as you need to. Shutting off vibration will also provide an even longer battery life.

Notification Panel/Quick Toggle View



**TIMEKEEPING:** Alarms vibrate to alert you at a time you have set. Set up to three alarms to occur once or on multiple days of the week via the ITOUCH Wearables App.



**Controlling Alarms on your Smartwatch:** You can toggle alarms on/off right from your smartwatch as well. Swipe down from the main clock face screen to reveal the notification panel. Tap on the 'Settings' icon. Navigate to Alarms and tap on it. Here, you can see the three alarms you've set and have the ability to turn them off/on as you need. *Please note: In order for alarm changes to take effect, your device needs to sync with the ITOUCH Wearables App.*



You can also time events with the stopwatch feature on your K+K Smartwatch. On the main clock face, swipe right and scroll down to the 'Settings' option. Tap on 'Stopwatch' on the next screen. To begin recording a time, hit the 'Play' button. To exit the stopwatch function, swipe right.

**NOTE:** Your smartwatch shows you the time you see on your smartphone. While traveling, once your mobile device syncs with the updated timezone, your watch will display the updated time frame too.

## NOTIFICATIONS & MESSAGING



K+K Smartwatch can display call, text, social media, and app notifications from your smartphone to keep you informed. The Smartwatch and phone device must be within Bluetooth range of each other to receive such notifications.



**Set Up Notifications:** Check that the Bluetooth on your phone is on and that your phone can receive notifications (often under **Settings > Notifications**). Then set up notifications:

1. In the ITOUCH Wearables App, tap the 'Menu' icon and tap settings then, go to **Watch Notifications**.

2. From **Watch Notifications**, you may select the notifications you wish to receive on your Smartwatch.

**Note:** Notification permissions differ between iOS and Android users.

**Viewing Incoming Notifications:** When your K+K Smartwatch and smartphone are within range, notifications cause the Smartwatch to vibrate. If you don't read the notification when it arrives, you can check it later by navigating to **Messages** on your Smartwatch. To view unopened messages and notifications on your K+K Smartwatch, on the main clock face screen, swipe up from the bottom of the screen to reveal the Messages screen. Tap on any message found in this section to reveal more information about it. To exit the messages feature, swipe down from the top of the screen or swipe right on the screen.

**Manage Notifications:** K+K Smartwatch stores up to 5 notifications, after which the oldest are replaced as you receive new ones.



**Turn off Notifications:** Turn off all or certain notifications with the ITOUCH Wearables App from Watch Notifications in the settings menu. You can also mute all notifications by turning on **Do Not Disturb** mode. Learn more about the Do Not Disturb function in the **Additional Features** section of the manual.

**\*Note for Android Users\*** The 'Other' function was created to help provide notifications from apps you want to receive information from that support hasn't been built for directly. For Android Users, while 'Other' is on, all notifications that appear within your smartphone's notification panel will be displayed by the watch.

## ACTIVITY & SLEEP



K+K Smartwatch continuously tracks a variety of stats whenever you wear it. The information is then transferred to the ITOUCH Wearables App every time you sync your Smartwatch. We recommend syncing your Smartwatch to the app at least once a day.

**See your core stats:** Steps taken, calories burned, and distance covered. Find your complete history and other information automatically detected by your Smartwatch in the iTouch Wearables App.



**Track Daily Goals:** K+K Smartwatch tracks your progress towards daily goals based on the goals you set when first setting up your account. When you reach your goal, the app will send you a push notification that the goal is completed. If a step goal is achieved, your smartwatch will vibrate and show a celebratory badge.

## SEDENTARY REMINDER



Turn on reminders to move in the app to set a sedentary reminder alert. The sedentary reminder can be enabled in the **Settings Menu** by tapping on the 'Reminder To Move' selection. When enabled, this feature is active during the hours of **10:00 AM - 6:00 PM**.

## TRACK YOUR SLEEP



Your K+K Smartwatch will automatically track your time asleep and sleep stages (deep sleep, light sleep and time spent awake). To see your sleep quality score and stats, sync your Smartwatch when you wake up and check the app.

**Learn about your sleep habits:** K+K Smartwatch tracks several sleep metrics including the amount of sleep you get and provides you with an overall sleep score number for that night. It will track your wake time and your light sleep time, along with deep sleep. In-app, you can tap on the Sleep card on your main home screen to see further details about your sleep history. Tapping on your sleep progress graph will allow you to see even more information by providing you with a 'Sleep Summary' for you to review.

## HEART RATE



The K+K Smartwatch tracks your heartrate throughout the day. To measure and see your real-time heart rate, navigate to the heart rate feature on your Smartwatch. Swipe left on your device until you land on the heart rate page.

Additionally, you can quickly get to this screen by swiping right on the main clock face and scrolling down to '**Measure HR**'. Both ways take you to the same screen. Tap on the screen when at the heart rate area. The watch will then vibrate, indicating it is reading your heart rate. Once completed, your watch will vibrate again and display your heart rate measurement.

**Continuous Heart Rate:** Your device also supports 24/7 heart rate detection. To activate this feature, navigate to settings in the app and tap on **Continuous Heart Rate Detection** to toggle it on and off. While this feature is active, your smartwatch will continuously record your heart rate every 30 minutes throughout the day. This data will automatically sync with your app when your K+K Smartwatch is within Bluetooth range of your smartphone. When continuous heart rate detection is turned on, your sleep statistics are more accurate. To preserve smartwatch battery life turn off continuous heart rate detection.

**Please note:** The graph on your watch within the Heart Rate section is connected to Continuous Heart Rate function. If this is off, the graph on your watch will no longer appear until turned on again.



Not a medical device. This device and related software are not intended for use in the diagnosis of disease or other conditions, or in the cure, mitigation, treatment or prevention of disease. Users should not interpret or take clinical action based on the device output without consultation of a qualified healthcare professional.

## FITNESS AND EXERCISE (MULTI-SPORTS MODE)



Track specific exercises, such as running, golf, football, basketball, and more with your K+K Smartwatch. Your Smartwatch is equipped with 8 sports modes. Each exercise tracks specific details such as steps, total time, average heart rate, calories and etc. Sports modes included are:



Hiking



Football



Running



Tennis



Outdoor Cycling



Basketball



Indoor Cycling



Golf

### Some Helpful Tips:

- For data to be saved, the workout/sport you do must be done actively for at least 3 minutes.
- Once you begin a sports mode, the exercise on the watch may show two pages appear (you'll notice this as two small dots will show at the middle-top of the screen), you can swipe left and right to see the data found on these pages.
- You can perform the sport either near your smartphone or away/not connected to your smartphone. Once the device comes within Bluetooth range of your smartphone, it will automatically sync with the app and the mode will appear on your home/dashboard screen in app.
- Sports modes should be done one at a time. After stopping one mode, ensure that the data is synced to the app first. Then start your second sports mode. Doing multiple modes at once, without syncing to the app will cause data you have acquired to be lost.
- The watch will alert you if the activity time is too short to record. Activities not performed for at least 3 minutes will not be saved to the app/watch.

You can view all of the sports modes you have done for the day as well as the calories burned doing each activity within the Calories card found on the main home page of the iTOUCH Wearables App.

## CONNECTED GPS



For complete workout stats, recap, route and pace information, make sure to use your smartphone's connected GPS. Review your exercise history via the ITOUCH Wearables App.

Note: The Connected GPS feature on the K+K Smartwatch works with the GPS sensors of your nearby smartphone.

To use Connected GPS from the main home page of the app, tap on the 'Menu' icon and select Running Mode. A new screen will appear with a start button will appear (iOS users – You may be asked for location permissions here – Please tap 'Allow While Using App' to proceed forward). Tap Start to begin tracking. Connected GPS mode will be enabled until you pause or completely stop it. This screen will showcase your heart rate and calories burned. You will have an option to toggle between this screen and an actual live map of your route. Once completed, you can view your distance traveled and check previous records of your routes.

## SMARTWATCH FEATURES



**MUSIC REMOTE:** To remotely control music from your smartwatch, navigate to the music feature on the K+K Smartwatch (it is the last screen on the watch when swiping left). The music remote allows you to play/pause, skip forward, or skip to previous music from your music apps. Your K+K Smartwatch is compatible with various applications such as Apple Music, Spotify, and Pandora. However, it may not support other third party applications.



**CAMERA REMOTE:** To snap photos using your K+K Smartwatch, navigate to the camera remote function. With the app open, navigate to the settings page and tap Camera Remote. This will launch the built in app camera (iOS Users: Tapping on Camera Remote will advise you to open up your native camera to take pictures with your watch). To take a picture, tap on the Camera Remote icon on your smartwatch or shake your wrist and your phone will take a picture.

## ADDITIONAL FEATURES

From the home screen in app, tap on the 'Menu' icon and tap **Settings** to view more features available for your Smartwatch. Learn more below.



**WEATHER:** Once your smartwatch is fully paired to the app, open the ITOUCH Wearables App. Navigate to the settings page, scroll down and tap on 'Weather'. Your location should be automatically found or you can enter your location information in manually. Once done, instantly the watch will update with the latest weather readings. From the Weather screen on your smartwatch, you can tap the screen to view more weather data. Your smartwatch shows the weather forecast for 5 days and updates hourly (as long as you are connected with the iTouch Wearables application on your mobile phone). You can also change the units of measurement for temperature here as well.

## ADDITIONAL FEATURES



The weather information is updated every two hours. If your device cannot update the weather during this timeframe, it will show no information.

This normally will only happen if your phone and device aren't connected. To correct this, use the iTouch Wearables application to connect your device to your phone again.

**\*Note For Android Users\*** When you fully connect to this device, you may see the weather as incorrect or not matching what you see from the forecast you're observing. This is due to Android now preventing some information to be sent from your phone to the watch. Follow the steps above to ensure your weather data is always updated.



**FIND DEVICE:** Tap **Find Device** under Settings to vibrate your K+K Smartwatch when paired with the app.

**LANGUAGE:** Tap **Language** under Settings to change the language on your Smartwatch. Choose from a variety of languages.

**Note: setting the language on your iTouch device does not change the language setting of the mobile application.**

**DO NOT DISTURB:** Tap **Do Not Disturb** under settings in app and set a time period to prevent your Smartwatch from receiving all notifications (other than alarms). Once active, it takes 3-5 minutes to begin working.

**TIME FORMAT:** Tap on **Time Formats** under Settings to select between 12 and 24 hour format.

**UNIT FORMAT:** Tap **Units** under Settings to change the units of measurement reflected on your Smartwatch and/or app. Choose between the metric and imperial systems of measurement for your watch. You can choose other units that you can see in app within this section as well.

## UPDATE, RESTART, AND ERASE

**Update Smartwatch Firmware** If there is a new firmware update available for your K+K S Smartwatch, you will receive a pop-up notification to download it within the ITOUCH Wearables App. If you do not receive said notification, tap the 'Menu' icon and then select settings. Scroll down to Update Firmware where you will see a red dot on the Update Firmware tab, signifying that an update is available. Tap the Update button to begin updating your K+K S Smartwatch. Be sure that your Smartwatch remains within Bluetooth range of your phone while updating. Once your update is completed, your watch will automatically reset.

**Restart Your Smartwatch:** If you can't sync your K+K S Smartwatch, or if you have trouble with connected GPS or tracking stats, you can restart your smartwatch from your wrist. From the main clock face, swipe down to reveal the notification panel and tap on settings. When in settings, scroll down to 'Power Off' and tap on it. Tap on the blue check mark that appears next to power off your device. Allow your device a few minutes to fully shut down. Then tap and hold the screen of your device for 3-5 seconds to turn it back on to complete your restart.

## WEAR AND CARE

All K+K Wearable products are meant to be worn all day and night, so it's important to follow a few simple guidelines as you wear and care for your device.

To keep your band clean and your skin happy, we recommend the following tips:

- Clean your band and wrist regularly - especially after intense workouts or sweating.
- Rinse the band with water or wipe it with a small amount of rubbing alcohol. Do NOT use hand soap, dish soap, hand sanitizer, cleaning wipes or household cleaners, which could get trapped beneath the band and irritate your skin.
- Always pat dry the band before putting it back on



**Note:** Although the K+K S Smartwatch is IP67 water resistant, it is not IP68 waterproof which means you should not submerge your smartwatch in water deeper than one meter for longer than 30 minutes. We advise not to swim with your device. However, your K+K S Smartwatch can withstand many splashes, rain, and daily activities such as washing dishes. If your Smartwatch gets wet, we advise you to remove it until dry. It is not good for your skin to wear a wet band for long periods of time.

**IMPORTANT TIPS:** If you have allergies, asthma, or eczema, you may be more likely to experience a skin irritation or allergy from a wearable device. If you start to experience skin irritation or redness on your wrist, remove your device. Contact a dermatologist if symptoms persist longer than 2-3 days of not using your wearable device.

### REGULATORY & SAFETY NOTICES

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help. Caution: Any changes or modifications to this device not explicitly approved by the manufacturer could void your authority to operate this equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC RF radiation exposure limits set forth for an uncontrolled environment. This device and its antenna must not be located or operated in conjunction with any other antenna or transmitter.

**FCC ID: 2ARUI-ITF20SQ**

#### NON-MEDICAL DEVICE

This iTouch Wearables product is NOT a medical device. This device and related software and applications are NOT intended for use in the diagnosis of disease or other conditions, or in the cure, mitigation, treatment or prevention of disease. Users should NOT interpret or take clinical action based on the device output without consultation of a qualified health-care professional.